




Outline


- · Historical perspective
- · What makes semiconductors special?
- · Microelectronics: transistors & integrated circuits
- Optoelectronics
- Micromachines (MEMS*)
- Microsensors
- Microsystems
- * MEMS = Micro Electro Mechanical System





























What's So Special About Micro Technologies and Micro Systems?

- Microsystems <u>are not</u> the best choice for <u>every</u> application
- When Micro-Systems are the best choice it is because they do one or more of the following
 - Significantly reduce volume, weight and power
 - Significantly reduce cost
 - Significantly improve reliability
 - Perform functions that are not possible with macrosystems

13





Outline


- · Historical perspective
- · What makes semiconductors special?
- · Microelectronics: transistors & integrated circuits
- Optoelectronics
- · Micromachines (MEMS*)
- Microsensors
- Microsystems


14








































































































































- Use a physical property that can produce an electrical signal
 - e.g., current flowing in a wire or a transistor
 - e.g., vibrations along a solid surface
 - e.g., movement of a microscopic rod of material
- Find a way to have the thing we want to sense change that physical property and, thus, change the electrical signal
 - e.g., Hydrogen can change the current flowing in a transistor
- Design an circuit that can detect the change in the electrical signal when what we want to detect is present


Nation Labora


Micromachined Pressure Sensor Wafer 2 Wafer 1 Motorola Sandia Nation 59












































Acknowledgements Many of the visuals shown were generated by the Microsystems Staff at Sandia National Laboratories In New Mexico and California.

